



Installation Guide

GstarBIM 2025



GstarBIM
ARCHLINE.XP


GstarBIM 2025 Installation Guide

Users can visit www.gstarcad.net to download GstarBIM 2025 to your computer or server.


GstarBIM 2025 Install Wizard will guide the user to install the software in the operating system completely and successfully.

Please follow the steps below to install GstarBIM 2025:


1. Double-click the executable file downloaded.
2. If you didn't install DirectX before, it will ask to install DirectX first.




3. Click **Yes** to install DirectX
4. In **Installing Microsoft(R) DirectX(R)** dialog, read **License Agreement** and click "**I accept the agreement**" and **Next** button.




5. Click **Next** button to continue the installation.




6. You just need to wait for a few minutes for the [Overall Progress](#)




7. The [GstarBIM Install Wizard](#) dialog box will pop up.




8. Read **License Agreement and Privacy Policy** and click “**I accept the agreement**” and **Next** button.
9. Click **Browse** button and choose the destination path where setup will install the files.



10. Click **Next** button to continue the installation.
11. Confirm the Destination location, and click **Install** to continue the installation.



12. You just need to wait for a few minutes for the [Overall Progress](#).



13. The GstarBIM wizard has successfully installed GstarBIM 2025. Please check on [Run GstarBIM 2025](#) to startup GstarBIM 2025 or just click [Finish](#) button to exit the wizard.

