

GstarCAD Architecture 2017

User Guide

Catalog

1.	Preface.			3			
2.	Installati	Installation					
3.	Startup and Interface						
	3.1	Star	'tup	6			
	3.2	Inte	rface Introduction	6			
	3.3	Unit	t Setting	7			
4.	Design a	and Ope	eration	7			
5.	Case Stu	udy		9			
	5.1 Draw grids in plan drawing						
	5.2	Grid	I Dimension in plan drawing	10			
	5.3	Drav	w walls in plan drawing	12			
	5.3	3.1	Single Wall	12			
	5.3	3.2	Composite Wall	16			
	5.4	Drav	w columns in plan drawing	19			
	5.5	Drav	w Win-door in plan drawing	20			
	5.6	Drav	w corner windows in plan drawing	22			
	5.7	Drav	w U-shaped stair in plan drawing	23			
	5.8	Drav	w steps in plan drawing	24			
	5.9	Drav	w apron in plan drawing	25			
	5.10	Drav	w balcony in plan drawing	26			
	5.11	Drav	w roofs in plan drawing				
	5.12	Line	ear Dimension	29			
	5.13	Sub	join Dimension				
	5.14	Bay	Combine				
	5.15	Rem	nove Dimension				
	5.16	Roo	m Label				
	5.17	Elev	vation Dimension	34			
	5.18	Sec	tion Symbols Dimension	35			
	5.19	Inde	ex Symbol Dimension	35			
	5.20	Title	e Index Dimension				
	5.21	Title	e Mark				
	5.22	Viev	vport Symbol				
	5.23	Con	npass				
	5.24	Stag	ge exercise Summary and Drawing Process				
	5.25	Proj	ject Management				
	5.26	Gen	erate Elevations by Project Management	43			
	5.27	Gen	erate Section by Project Management				
	5.28	Gen	erate 3D model by Project Management				
	5.29	Sun	nmary				

Preface

Hello! This document will help you learn key features of GstarCAD Architecture. We will introduce GstarCAD Architecture in the following order: Installation -> Startup and Interface -> Design and Operation -> Case Study. You could access <u>www.gstarcad.net</u> for more information.

Installation

Download installation program from the company website:



Run the installation file

Double click to run the installation program and enter installation interface. Check "I accept ..." option and click "Next" button as shown in figure 2.

 I accept the terms of the license agreement 							
I do not accept the terms of the license agreement							
	< <u>B</u> ack	<u>N</u> ext >					

Accept the agreement

Check which function you need to install. It is recommended to accept all (install all functions by default). Destination Folder is used to specify installation directory. You could change installation directory by clicking "Browse" button.

Select the features you want to install,	and deselect the features y	ou do not want to install.
Executable file		0 K
✓ Examples		0 K
Drawing Library		OK
🔽 Demo		0 K
🗹 GistarCAD		OK
🗹 Mat Lib		OK
Destination Folder		
d:\Gstarsoft\GstarCAD Architecture		Browse
Concern Description Dr	٥K	
Space Required on D:	OK	Disk <u>Space</u>
Space Available on D:	К	
< <u>B</u> ack	<u>N</u> ext >	Cancel

Select which function to install

After selected functions and installation directory, click "Next" button to next step. In the following page, it prompts to select program folder, you could directly click "Next" button. It may take you several minutes to finish installation, and then click "Finish" button to exit. You could find program icon on the desktop and in the startup menu.

Startup and Interface

Startup

Double click GstarCAD Architecture icon



and enter startup interface.

In the following interface, you could select Activate or Try. If you have purchased a license, you could click "Activate" button; otherwise, you could click Try to use in the trial period. And then, it displays startup interface.



Activate or Try

Interface Introduction

GstarCAD Architecture interface is shown as below:



Interface introduction

The main functions are integrated into the toolbox. It is most commonly used in actual drawing. You could find all functions by clicking pull-down menu in the toolbox. GstarCAD Architecture also provides general functions of CAD platform, such as Move, Copy, Mirror, Delete, and so on. To master GstarCAD Architecture requires the capability of using CAD.

If closed the toolbox dialog box by mistake, you could display it by pressing combination key "ctrl + =".

Unit Setting

When designing construction drawings, users have to set up the drawing unit. That is what one unit stands for. For example, by default 1 unit stands for 1mm. If there is no special announcement, the contents of this passage will use the mm units. When using GstarCAD Architecture the users can set the unit in the Units Setting at the bottom left corner according to their needs



Unit Setting

Design and Operation

GstarCAD Architecture is designed from the architects' points of view, and you could master it and apply it to practical work in a short time. The main work of architecture design is focused on plan drawings, let's introduce as below:

1. Draw location grids and axis tags in plan drawing, and set reference guide lines.

2. Draw walls in plan drawing, and determine function rooms division and their positional relationship.

3.Draw columns in plan drawing.

4. Draw doors, windows, and holes in plan drawing.

5.Draw stairs in plan drawing.

6.Draw balconies, steps, and aprons in plan drawing.

7.Draw roofs in plan drawing.

8.Dimension.

9.Symbols.

10.Text and table.

11. Project Management (relationship of architecture plan, model, elevation, and section).

12.Draw elevation and section.

13.Assemble and export 3D model.

Case Study

In the following page, taking an example of a small modern style villa, you could study some commands of GstarCAD Architecture (hereafter called GCA) and experience most of its functions.

Draw grids in plan drawing

Objective: Draw location grids and set reference guide lines in plan drawing. Methods: Draw Grid command.

(1) After starting the Draw Grid command, the following dialog box pops up. It could export parameters by entered table.



Draw Grid dialog box

The following table is grid parameters of first-floor plan drawing.

	Bay Size	Number
Bottom	4500	2
Left	4500	3

(2) Click Ok to preview grids. You could specify grid insertion position and insertion way in model space according to prompts displayed in the command line as shown below:



Insert grids

(3) Insert grids by clicking anywhere in the drawing area.

Grid Dimension in plan drawing

Objective: dimension on created grid Methods: Grid Dimension command

(1) Click Grid Dimension command in menu;

- ONITON ANTS DIR			
Grid Dimension			
	s and the end axis and label each a	xis number and size	
tet Add Avie Number	Axis Label	×	
Start Axis Label	Axis Label Share	d	
Axis Tag Ruler	🗸 🔘 One Side	Both Sides	
Ignore partial aixs	✓ Dimension Size	Dimension on Another Side	
C Select	start axis line or intersected axis line	e to dimension: 41443 19746	
+ + + + + + + + + + + + + + + + + + + +	-+ -		

Grid Dimension

(2) Specify the start point and end point according to prompts, the ruler of specifying start point and end point is displayed as below: (p1 is start point, p2 is end point);



(3) It creates dimensions and tags by selection order. If the order is reversed, all tags will reverse. You could practice to draw grids and create dimensions as shown below:



Finish grid dimensioning

There are many other settings, you could learn more by Help document or practice.

Draw walls in plan drawing

Objective: draw walls, and divide the region into various types of rooms. Methods: Draw Wall command.

Wall-drawing can be divided into two types: One is Single Wall. The other is the Composite wall. Single Wall is made of one kind of material, but the Composite wall is made of a variety of materials.

Single Wall

(1) The Wall dialog box pops up after clicking Draw Wall command. You could set Single Wall parameters in this dialog box, such as Single Wall, Height, Thickness, Materials, the purpose of use, and so on.

Tool Box Grid Column/Beam/Sta Wall Draw Wall Draw double-Line vertical wall and curved wall continuously	w Wall
(2) Dra	w Wall
Wall Type	asic Parameter
● Single Wall Wall Material: Brick Wall 🗸 🗸	Height: 3000 🗸 Bottom Elevation: 0 🗸
Composite Wall Style Manager	Width: 100 Usage: Common Wall V
1 BW 50 Reinforced-concrete	
	Reference Whole Wall V
	Center Line Ceft Edge Right Edge
	From Left Edge 0
	•
	(1)(0)
3 [®] [©] ^{Straight wa}	Ill next point or 3539<270°
Û	2 3

Single Wall

(2) The wall is related to drawing direction. For example, P1 is the start point of the wall, and P2 is the end point of the wall, you could see the different associations of Base Line and Wall Direction as shown below:

Basic Parameter Height: 3000 V Bottom Elevation: 0 V	P2
Width: 100 Usage: Common Wall Base Line Reference Whole Wall Image: Common Wall Image: Common Wall Image: Common Wall Image: Common Wall Image: Common Wall Image: Common Wall Image: Common Wall Image: Common Wall Image: Common Wall Image: Common Wall Image: Common Wall Image: Common Wall Image: Common Wall Image: Common Wall Image: Common Wall Image: Common Wall Image: Common Wall </td <td>C Straight wall next point or Another segment Arc wall(A)</td>	C Straight wall next point or Another segment Arc wall(A)
O From Left Edge	

Base Line at the Center



Base Line from Left Edge



Wall Base Line From Left Edge

(3) Double click wall to edit it. The color of the wall is related to the left edge and right edge.



Association of wall left or right position with wall direction

(4) You could edit walls by some commands of CAD platform, such as Copy, Move, Rotate, Trim, Extent, and so on; and practice to draw walls as shown below (wall width is 200 mm by default, but it could be customized):



Finish wall dimensioning

Composite Wall

(1) The Wall dialog box pops up after clicking Draw Wall command. You could set Composite Wall parameters in this dialog box, such as Composite Wall and other parameters.

Tool Box	ť	י × 🪄	Composite Cavity Wall 🙁				
Grid		-					
Column/Beam/Slab -							
Wall	-	-					
— Draw W	all (1						
Draw do	puble-Line v	vertical wa	II and curved wall continuously				
(2)				Draw Wall ×			
-Wall T	уре			Basic Parameter			
🔾 Si	ngle Wall	Walls	Style: CMU-190 Cavity Wall 🔷 🗸	Height: 3000 🗸 Bottom Elevation: 0 🗸			
🖲 Co	omposite Wa	ll	Style Manager	Width: 100 Usage: Common Wall 🗸			
N	o. Width	Priority	Material Name	Base Line			
1	90.00	10	Brick Wall Column				
2	50.00	12	Air Gap	Reference Whole Wall 🗸			
3	40.00	15	Rigid Insulation	Center Line Left Edge Right Edge			
4	190.00	65	CMU	O From Left Edge 0			
		-\$- M		· · · ·			
		- - - 101					
		3 -	- 	T T T T T T T T T T T T T T T T T T T			

Composite/Cavity Wall

(2) In the drop list of the Wall Style, users can choose a suitable composite wall style and then draw it. If the present styles can not meet your requirement, the user can click the "Style Manager" button and then jump to the page of composite wall style management. Here, you can set up or modify the wall style.

Wall Type								
◯ Single Wall	Wall 9	Style:	CMU-190 Cavity W	/all 🗸				
Composite Wall			Standard CMU-190 Cavity W	/all				
No. Width	Priority	riority Material Name						
1 90.00	10	Brick	Wall Column					
2 50.00	12	2 Air Gap						
3 40.00	15	Rigid Insulation						
4 190.00	65	CMU						

Select a Wall Style

Wall 9	Style: CMU-190 Cavity Wa	el V	G				I	Drawing Sett	ings
	Style Manag	er 🚽	Basic	Settir	ngs Materia	l Style W	all Style		
Priority 10	Material Name Brick Wall Column		Wa	ill Style	e Name:	CMU-190	Cavity Wall	~	New
12			Detail Property: Standard CMU-190 Cavity Wall		Cavity Wall				
15 35	Rigid Insulation CMU			No.	Width(mm)	-	Material	Standard Hatch	Scale
	CINO			1	90.00	10	Brick Wall Column		1.0
				2	50.00	12	Air Gap		1.0
				3	40.00	15	Rigid Insulation		0.4
				4	190.00	65	СМИ		3.0
			-						

Wall Style Manager

- (3) The wall is related to drawing direction. For example, P1 is the start point of the wall, and P2 is the end point of the wall, you could see the different associations of Base Line and Wall Direction as shown below:
- (4) Double clicking the wall to edit it. The color of the wall is related to the left edge and right edge.



Association of composite wall left or right position with wall direction

(5) Clicking the arrow of grip point in the wall, this can change the wall direction.



Control grip of wall direction

Draw columns in plan drawing

Objective: draw columns in plan drawing and initially complete the structural arrangement.

Methods: Standard Column command.

GCA provides a variety of column types and ways to insert. It is very simple to edit columns, for example, you could edit a column by dragging grips on it. It also supports some commands of CAD platform, such as Copy, Move, Rotate, and so on.

(1) Start Standard Column command, enter 400 X 400 to set column size in the dialog box, insert the column to the drawing, and place it to an appropriate position. Steps as shown below:

Column/Beam/Slab	
EStandard Column (1)	
Insert square column, cylinder, or octagonal colu	non at avic intersection
Construction Column Construction	
Standard	Column (2)
	Column Size Eccentric/Angle
Material: Reinforced-ci V	Length 400 V X-Offset 0
Shape: Rectangle 🗸	Width 400 V-Offset 0
Elevation: 0	Height Default_He V Angle 0 V
+ # ¥ ₩ ₩ ₩	
3	A Move to appropriate position

Column

(2) The effect of the column is related to settings for materials, scale factors, and hatch mode. It is helpful to master settings for them when drawing or editing columns. View effect as below:

	Default Effect	Switch between thicken and no thicken	Switch between fill and no fill of 2D walls
Drawing Library Command:			
Drawing Library Command:			

Effects of different settings for scale factors, bold, and hatch

Wall	Material: Brick Wall	Material: Brick Wall	Material: Reinforced-concrete
Column	Material: Reinforced-concrete	Material: Brick	Material: Reinforced-concrete
Drawing Library Settings and Help Scale 1:100 Unit:mm 61971, 151380, 0			
Drawing Library Settings and Help Scale 1:50 Junit:mm 68623, 151455, 0			

Effects of different settings for scale factors, materials, bold, and hatch

(3) There are many other settings, you could learn more by Help document or practice.

Draw Win-door in plan drawing

Objective: draw Win-door on the wall.

Methods: Door/Window command.

GCA provides a variety of Win-door styles, including plan and elevation styles. It supplies some parameters, such as width, height, distance from sill bottom to ground, tag, classification, and so on; it also offers many ways to insert win-doors. The dialog box could help designers draw win-doors in a simple way.



Door and Window dialog box

Steps to insert a door without tag:

- (1) First to make sure that there is wall segment with sufficient width in drawing;
- (2) Click Win-door command;
- (3) Click Door icon in dialog box;
- (4) Set insertion way to be distance from wall pier;
- (5) Set tag to be empty; set door width to be 1000, door height to be 2200, number to be 1, and Offset distance to be 200;
- (6) Click on the wall to finish door insertion.



Steps to insert a window with tag:

- (1) First to make sure that there is wall segment with sufficient width in drawing;
- (2) Click Win-door command;
- (3) Click Window icon in dialog box;
- (4) Set insertion way to be wall center;
- (5) Set tag to be auto, window width to be 1200, window height to be 1500, and number to be 1;
- (6) Click on the wall to finish window insertion.



Operation Guide for Window

The parameters in the Win-door dialog box is very simple, you could practice inserting different types of doors, windows, bay windows, and holes.



Insert Bay Window

Rectangle Opening ×	111/2014
Tag: Auto Tag V Opening Height: 2400.0 V	H1524
Type: Wall Opening V Bottom Elevation: 0.0 V	
Opening Width: 1500 v umber: 1 🔷	
Tag Check	
≖≟ᅖᆋबୖଢ଼ଢ଼፠๓ᇚ╣श∥╝╻๓๛๚ӽҵ <mark>ҏ</mark>	
Insert rectangle openin	g

Insert Hole

You could also edit inserted win-doors by command of CAD platform, such as Copy, Move, Delete, and so on.

Draw corner windows in plan drawing

Objective: insert corner windows to the wall corner.

Methods: Corner Window command.

- (1) First to make sure that there is an appropriate wall corner in drawing;
- (2) Click Corner Window command;
- (3) Set window width 1 to be 1000, window width 2 to be 1500 (it could be changed according to specified circumstance. Preview it by moving mouse to wall corner, and then edit values of window width);
- (4) Click on wall corner to finish corner window insertion.



Operation Guide for Corner Window

You could edit corner window style by dragging grips on it.



Grip editing for Corner Window

The dialog box is very simple, you could try to modify parameters and enjoy different effects.

Draw U-shaped stair in plan drawing

Objective: insert appropriate stairs to draw.

Methods: U-Shaped Stair command.

GCA provides lots of stair styles. In this guide, we will introduce the most commonly used U-shaped stair. You could draw and edit your drawings by GCA and get a deeper understanding of it.

- (1) First to make sure that there is an underlay in drawing;
- (2) Click U-Shaped Stair command;
- (3) Set Staircase width to be 1900 (it could be changed according to specified circumstance. Preview it by moving mouse to wall corner, and then edit values of window width);
- (4) It displays the preview effect when moving the mouse to the drawing area. Note: it is unnecessary to specify stair location by clicking.
- (5) Please pay attention to command prompts in the command line, enter "A" to rotate inserted stair by 90 degrees. You could rotate several times and place it to an appropriate position.



Operation Guide 1 for U-Shaped Stair

- (6) Specify stair insertion position to complete.
- (7) You could edit stair parameters in the dialog box by double clicking the stair.

(8) Set floor type to be the first floor and click OK. It displays the final stair style (if you have already familiar with effects of different settings, you could set them all at the beginning).



Operation Guide 2 for U-Shaped Stair

The dialog box is very simple, you could try to modify parameters and enjoy different effects. You could also edit inserted stairs by command of CAD platform, such as Move, Copy, Rotate, Mirror, Delete, and so on. GCA supplies grip editing functions, you could edit stair by dragging grips on it.

Draw steps in plan drawing

Objective: draw appropriate steps in the drawing.

Methods: Step command.

After clicking Step command, it displays a dialog box, at the same time you should pay attention to command prompts in the command line. You could draw steps by specifying its start point and end point.

- (1) First to make sure that there is an underlay in drawing;
- (2) Click Step command;
- (3) In the dialog box, set platform width to be 1500 mm; select Endpoint Location for insert way, select Rectangle Single Side Step, General Step, and Landing Surface.
- (4) Specify the first insertion point; in the process of inserting the second point, you could see the step direction and you could switch direction by pressing F key.
- (5) After specifying the second point, you complete drawing steps.

T-Shaped	Steps	×
📊 W-Shaped		
Double L-Shaped	Step Height: 450 Step Number: 3 🔹 🔽 Draw Edge Seal Line	
🙆 Triangle Stair 🋲 Scissors Stair	Tread Width: 300 Base Elevation: 0 Start without Step	
Rectangular Cor	Riser Height: 150 Platform Width: 1500 (3) End without Step	
Elevator	 Opening Extension: 400	ng
✓Escalator		
Balcony	Endpoint Location Rect Single-Side Step Based on the platform 답 법 습 웹 圖 人 답 면 된 당 같 % 데 면	_
H P	rt prepared pline graphic to step D1522	
3D Modeling * Elevation * Section * Text and Sheet Dimension * Symbol * Site Plan Desig File and Layout	Y 4 P2 7	5

Operation Guide for Step

If steps intersected with a column, GCA will auto process it as shown below:



The dialog box is very simple, you could try to modify parameters and enjoy different effects.

You could also edit inserted steps by command of CAD platform, such as Move, Copy, Rotate, Mirror, Delete, and so on. GCA supplies grip editing functions, you could edit step by dragging grips on it.

Draw apron in plan drawing

Objective: draw appropriate aprons in drawing.

Methods: Apron command.

After clicking Apron command, it displays a dialog box, in which you could set apron parameters to draw appropriate apron in drawing.

- (1) First to make sure there is an underlay in drawing;
- (2) Click Apron command;
- (3) Set parameters in pop-up dialog box, and click Search to Auto Generate;
- (4) Box select the first-floor plan as shown below in blue frame:

(5) After setting, the new apron automatically generated. If the apron meets columns, steps, or balcony, it will be hidden automatically.



Operation Guide for Apron

The dialog box is very simple, you could try to modify parameters and enjoy different effects. You could also experience different ways to draw apron.

Apror	ı ×
Floor level difference from ground: 450	Apron around Column
Plinth Offset from Outside Wall: 0	 Apron around Balcony Apron around Wall
Apron Width: 600	Create platform from ground level
💾 🖳 🖳 Select existed path to generat	te
Custom Draw	

Other ways to draw aprons

Draw balcony in plan drawing

Objective: draw a balcony in the drawing.

Methods: Balcony command.

After clicking Balcony command, it displays a dialog box, in which you could set balcony parameters to draw an appropriate balcony in drawing.

- (1) First to make sure that there is an underlay in drawing;
- (2) Click Balcony command;

- Set parameters in pop-up dialog box, set Railing Height to be 1100 and click Rectangular Three Sides Balcony;
- (4) Specify the start point of balcony in drawing as p1 shown in drawing, and specify the second point of the balcony as p2. You could adjust balcony direction by press F key.







The dialog box is very simple, you could try to modify parameters and enjoy different effects. You could also experience different ways to draw balcony.

		Balcony	×
	Peiling Width	Railing Width: 100 Railing Height: 1050 v Outreach: 1500 Ground Elevation: -50	☐ Section Drawing.dwg Sill Height: 900 ♥ Eave Length: 0 Insulation Thickness:
Rectangule Triangle Balcony	_	alcony Slab Thickness: 100 cony Beam Height: 350	Top Floor Balcony
Concave Balcony			path to generate
Internal Corner Balco Offset Draw		Custom Draw	
	M/au	a ta duam halaan.	

Ways to draw balcony

Draw roofs in plan drawing

Objective: draw a roof in drawing.

Methods: Roof command.

- (1) Draw the roof side line in plan drawing and it must be closed pline;
- (2) Click Roof command;
- (3) Select the created pline according to command prompts;
- (4) Press Enter key, enter slope angle and other parameters by default, and then press Enter key again;

(5) Finish drawing roof.



Operation Guide for Drawing Roof

The dialog box is very simple, you could try to modify parameters and enjoy different effects. You could also experience different ways to draw roof.

Linear Dimension

Objective: Linear dimension in the drawing.

Methods: Linear Dimension, Subjoin Dimension, Bay Combine, Remove Dimension.

GCA supplies intelligent object technology for dimensions. It has something different from GstarCAD. You should use special dimensioning functions of GCA to create and edit dimensions, such as Linear Dimension, Subjoin Dimension, Bay Combine, or Remove Dimension, rather than use dimensioning functions of GstarCAD. Styles of GCA are also different from GstarCAD. You could create new styles and apply them on dimensioning objects.



Different of dimension objects between CAD and GCA

After clicking Linear Dimension command, specify two points on dimension object, and continuous specify other points in the same direction, and then dimensions are automatically added. After all operations of Linear Dimension command, all added dimensions are a whole part.

- (1) Specify objects to dimension in plan drawing;
- (2) Click Linear Dimension command and pop-up a dialog box;
- (3) Specify p1 and p2 to locate dimension line as the start point and end point, specify p3 to determine the location of dimension line;
- (4) Continuous specify other points for automatic dimensioning along dimension line, such as p4.
- (5) Press enter key to finish. All dimensioning objects are a whole.





Operation Guide for Linear Dimension

Subjoin Dimension

Objective: dimension in the drawing.

Methods: Subjoin Dimension.

GCA supplies intelligent object technology for dimensions. It has something different from GstarCAD. You should use special dimensioning functions of GCA to create and edit dimensions, such as Linear Dimension, Subjoin

Dimension, Bay Combine, or Remove Dimension, rather than use dimensioning functions of GstarCAD. Styles of GCA are also different from GstarCAD. You could create new styles and apply them on dimensioning objects. You could subjoin dimension based on existing dimension. Clicking the dimension to subjoin on selected plan and clicking the position to place the subjoined dimension, a new dimension will be created based on existing dimension.

- First to make sure that there is existed dimension object in GCA and there is at least one object needed to be dimensioned;
- (2) Click Subjoin Dimension command;
- (3) Select existed GCA dimension object;
- (4) Specify the point to dimension, such as P1;
- (5) A new dimension is subjoined.



Operation Guide for Subjoin Dimension

The operation step is very simple, you could try to modify parameters and learn more.

Bay Combine

Objective: edit dimension in drawing and combine two bays.

Methods: Bay Combine command.

GCA supplies intelligent object technology for dimensions. It has something different from GstarCAD. You should use special dimensioning functions of GCA to create and edit dimensions, such as Linear Dimension, Subjoin Dimension, Bay Combine, or Remove Dimension, rather than use dimensioning functions of GstarCAD.

(1) First to make sure that there is existed dimension object in GCA;

- (2) Click Bay Combine command;
- (3) Box select the arrow which connects with two bays;
- (4) Finish combining bays.



Operation Guide for Bay Combine

The operation step is very simple. You could try to modify dimension styles to learn more, and it could make work easier to combine Bay Combine command with Subjoin Dimension command.

Remove Dimension

Objective: edit dimension in drawing and remove a part of unnecessary dimension in GCA.

Methods: Remove Dimension command.

GCA supplies intelligent object technology for dimensions. It has something different from GstarCAD. You should use special dimensioning functions of GCA to create and edit dimensions, such as Linear Dimension, Subjoin Dimension, Bay Combine, or Remove Dimension, rather than use dimensioning functions of GstarCAD.

(1) First to make sure that there is existed dimension object in GCA;

- (2) Click Remove Dimension command;
- (3) Select unnecessary dimension bay;
- (4) Finish removing unnecessary dimension bay.



Operation Guide for Remove Dimension

Room Label

Objective: label room's mark in drawing

Methods: Search Room command

GCA supplies intelligent custom object technology. Room objects include room name, area, hatch, and so on. GCA could generate room objects by Search Room command in a fast way, on condition that the room is a closed region surrounded by wall objects of GCA. You could set which objects to display when generating room objects.

- (1) First to make sure that there exists building plan drawing and walls are connected and closed;
- (2) Click Search Room command;
- (3) In the pop-up dialog box, check Display Room Name, Dimension Area, Area Unit;
- (4) Box select walls in drawing, and pick p1 and p2;
- (5) It automatically generates room objects, including room name and area.



Operation Guide for Search Room

- (6) Click Object Edit command;
- (7) Select the room object to edit;
- (8) Enter "Study Room" in Name place;
- (9) The result displays as below.



Room Object Editing

The dialog box is very simple, you could try to modify parameters and enjoy different effects.

Elevation Dimension

Objective: elevation dimension for plan drawing.

Methods: Elevation Dimension command.

In architecture plan, the ground elevation could be marked by Elevation Dimension function. Steps are as below: set elevation value and specify dimension location, and then specify text position.

- (1) Move the drawing to an appropriate position;
- (2) Click Elevation Dimension command;
- Select Ground Elevation in pop-up dialog box and set it to be "0 "(or set to a value according to your requirement, unit is m);
- (4) Pick a point to locate elevation and specify text position in plane;
- (5) Finish elevation dimensioning.

Door and Window 👻	Elevation Mark
Room and Roof + Stair and Others + 3D Modeling + Elevation +	Elevation Floor No./Description 0.000 Style: Overtical Elevation Ground Elevation
Section + Text and Sheet + Dimension +	Base Elevation Associative Elevation Select Datum<
Symbol Subscription Dimension Subscription Modify Subscription dimension for Subscription dimension dimension for Subscription dimension dime	✓ Manually Input Select Clear Accuracy: 0.000 ✓ ✓ Detail 2 elevation/section drawing and plane drawing
A Room B.12m ² ±0.000 C Comman	signed and the second s

Operation Guide for Elevation Dimension

The dialog box is very simple; you could try to modify parameters to experience many effects.

Section Symbols Dimension

Objective: section symbols dimension in plan drawing.

Methods: Section Symbol Dimension.

Select the position to mark key section position and create section line by Section Symbol command. The section line is a very important line for generating section drawing.

- (1) Move the drawing to an appropriate position;
- (2) Click Section Symbol Command;
- (3) Set section serial number to be "1" in pop-up dialog box, and select Orthogonal Cut;
- (4) Specify section line start point p1 and end point p2 in drawing, and specify "View Direction" according to command prompt;
- (5) Finish drawing section symbol.



Operation Guide for Section Symbol

The dialog box is very simple, and you could try to modify parameters to experience many effects, including section line with turning.

Index Symbol Dimension

Objective: index symbol dimension in plan drawing.

Methods: Index Symbol Dimension command.

- (1) Move the drawing to an appropriate position;
- (2) Click Index Symbol Dimension command;
- (3) Set title index number to be "A16", index label to be "1", and index style to be pointing index;

- (4) Specify locating node point p1 for index region in the drawing, and specify the diameter of index region by p2, and then specify turning point p3, at last, specify index tag position p4.
- (5) Finish index symbol dimensioning.



Operation Guide for Index Symbol

The dialog box is very simple, and you could try to modify parameters to experience different effects. The following are some index symbols styles; you could follow prompts to try.

	Index Symbol	×
O₂m²① °±Φ%	ወወወወ ረ២ዓ	
Index Text Index Draw Number: A12	Dimension Text Superscript Text:	~
Index Label: 1	Subscript Text:	✓
Text Style: A-LABEL	V Text Style: STANDARD	✓
	Text Height< 3.5 ✓	
Alignment of text with base line:	End 🗸 Continuou	st.
Direction Index	Add Index Range	gle 90 v
◯ Section Index		
Rectang	P1 P2 P3 A12	
		L SIA
	Index Symbol	×
-----------------------------------	--------------------------------	---
O₂m²① °± ¢ %	ወወወወ ረାወ∿	
Index Text	Dimension Text	
Index Draw Number: A12	Superscript Text:	~
Index Label: 1	✓ Subscript Text:	*
Text Style: A-LABEL	✓ Text Style: STANDARD ✓	
	Text Height< 3.5 ✓	
Alignment of text with base line:	End V Continuous	
O Direction Index	Multiple Section Position Line	
Section Index		

Style 1 for Index Symbol





Title Index Dimension

Objective: index title dimension in plan drawing.

Methods: Title Index command.

- (1) Click Title Index command;
- Set title index to be "A12" in dialog box, and title index to be "1"; check scale factor, and select scale factor "1:20";



Operation Guide for Title Index

The dialog box is simple, and you could try to modify parameters to experience different effects.

Title Mark

Objective: title mark in plan drawing

Methods: Title Mark command

- (1) Click Title Mark command;
- (2) Set title name to be "Ground Floor", and select scale factor to be "1:50" in dialog box;
- (3) Click the position to locate Title Mark;

Allen Title Mark 1 Citte Dim notes and scale Add drawing title and scale	C Title Mark × O2 m² ① ° ± Φ % Φ Φ Φ Φ ζ ⑫ ዓ.
	Ground Floor V 1:50 V Hide Text Style: A-STANDARD V Text Style: A-STANDARD V 1:50
	Text Height 7.0 Text Height 5.0 Traditional Style Record Scale National Standard Continuous
	Ground Floor 1:50 3 Ground Floor 1:50

Operation Guide for Title Mark

Viewport Symbol

Objective: Viewport Symbol dimension in plan drawing.

Methods: Viewport Symbol command.

- (1) Click Viewport Symbol command;
- In dialog box, set viewport index number to be "1", and set title tag to be "E12"; check fixed angle and value is "45" degrees;
- (3) Click the position to locate viewport symbol;
- (4) Finish viewport symbol dimension.

Symbol 🔺	Viewpo	ort Symbol ×	Viewport Index
		□ \Compart Number	Tag: 1
🚝 Elevation Modify	Viewport Index	Viewport Number	109.
式 Elevation Inspect	Tag: 1 🗸 🗸	Тор	Drawing No.: E12
Elevation Align	510	D V	brannigrio
🖉 Arrow Leader	Drawing No.: E12	Left C 🗸 A 🗸 Right	
Ç≜ Multileader		B 🗸	Text Style: A-LABEL 🗸 🗸
🗏 Composing	Text Style: A-LABEL 🔍 🗸	Down	Rotation: 180.0 🗸
🗝 Index Symbol 👝			
<pre> • View Symbol (1) • </pre>	✓ Fix Angle 45		
View Symbol			V
💭 Draw Cloud Line	10	/ 1 \	
🛨 Breakline		$(4) \qquad 1$	
##Symmetry Axis	FIPE C Plane calact dim	E12	E12 /
Compass	Li IX. C Please select dim	ension position 🔪 🖽 🖓 🦰	
ABoTitle Mark			

Operation Guide for Viewport Symbol

The dialog box is simple, and you could try to modify parameters to experience different effects.

Compass

Objective: draw compass on plan drawing.

Methods: Draw Compass command.

- (1) Click Draw Compass command;
- (2) Specify a point in drawing to locate compass center point;

(3) Specify compass included angle according to command prompts or specify compass direction by clicking in the drawing.

LiSection Symbol Draw Cloud Line Breakline ##Symmetry Axis Compass Draw compass Site Plan Desig File and Layout Building Desi	North Arrow Position <exit>:</exit>	North Arrow Direction<90.0>:
Common Tools	H + F Model Layout1	H A > H Model Layout1
Drawing Libra	<pre>Command: _OPEN Command: IcNorthThumb</pre>	Command: IcNorthThumb North Arrow Position <exit>:</exit>
🂯 Settings and	North Arrow Position <exit>:</exit>	North Arrow Direction<90.0>:

Operation Guide for Drawing Compass

Stage exercise Summary and Drawing Process

Objective:

- 1. Familiar with the operation of the previous commands;
- 2. Complete second and third-floor plan drawing work, preparing for underlay the next phase.

Methods: use previous commands and complete drawing the Basement floor, First floor, and so on, shown as below.



Plan drawings for all floors

All drawings for different floors are put together in one DWG file.

Project Management

Objective: build a model based on all drawings for different floors.

Methods: Project Management command.

You could build 3D models, and generate elevation drawings (2D) and section drawings (2D) by all floors of drawings. The 3D model could be combined by Project Management function.

(1) Click Project Management command. It displays a dialog box as below:

Site Plan Design 👻 File and Layout 🔺	Project Manager	×
Project Management (1	Project Management 🗸 🗸	^
Insert Frame	Sheet Set 👻	
Start speciality project ma	anagement interface	
💾 Define Viewport	🖻 🖻 🔂 🗂 🏛	
🙌 Cutting for Detail	NO. Height File	
🌃 Change Scale		
🖒 Layout Rotate		
🚮 Switch Workspace		
📲 Viewport to Block		
🔗 Building Design		
😿 Common Tools		~
Drawing Library	🔞 Project Management	
🂯 Settings and Help	Tools	

Operation Guide 1 for Project Management

- (2) Click New Project in pull-down menu and display a new dialog box;
- (3) Enter the name as "project-1" and keep other options to be the default. Click Ok to finish.
- (4) New project status: you could find "project1" file folder in a specified position, and there exists a named "project-1.ipj" Project Management file. It means the project is created successfully. You could open previously existed project by clicking its "*.ipj" file, through Open Project command under Project Management menu.



- Operation Guide 2 for Project Management
- (5) Save the plan drawing to specified file folder, we could name it "plan.dwg" for example.



Operation Guide 3 for Project Management

(6) Return to Project Management dialog box; click Floor Table menu, enter "1" for floor tag and enter "3000" (mm) for floor height, it means the height of the first floor is 3000 mm. Note: floor height is different from objects height of floor (such as wall height, or column height). In general, floor height should be the same as objects height, which is very import for elevation and section drawing.



Operation Guide 4 for Project Management

(7) Confirm that current floor is the first floor. Click Box Select Floors and then box select the plan region of the ground floor according to command prompts; specify the Base point of floors for alignment(base points for other floors should be at the same position in their specified region).





(8) Now the drawing region and content are determined. In the Project Management dialog box, it prompts that the content of the first floor is "plan < box selection >". You could view current box selected region and alignment point by clicking Show and Refresh Define Frame of floor button. If there is something wrong, you could repeat step 7. The floor frame could be hidden by clicking Hide Define Frame of floor button.



Operation Guide 6 for Project Management

(9) The complete definition of floors (from first floor to fourth floor) by repeating steps (from step 6 to step 8).

Project Manager	a ×	plan 🗶			
Project-1	~				
Sheet Set	+				
Floor Table	*				
🖻 🖻 📑 🗂 🏛					
NO. Height File			_		
-1 3000 plan <box select:<="" td=""><td>ion></td><td></td><td></td><td></td><td></td></box>	ion>				
1 3000 plan <box select:<="" td=""><td>ion></td><td></td><td></td><td></td><td>╟╁═╅┎┼╢</td></box>	ion>				╟╁═╅┎┼╢
2 3000 plan <box select:<="" td=""><td>ion></td><td></td><td></td><td></td><td>╟╫╧╪═╤╫╢</td></box>	ion>				╟╫╧╪═╤╫╢
3 3000 plan <box select:<="" td=""><td>i on></td><td>[₽][₽][₽][₽]</td><td></td><td></td><td></td></box>	i on>	[₽] [₽] [₽] [₽]			
▶ 4 200 plan <box select:<="" td=""><td>ion></td><td><u> </u></td><td></td><td>_</td><td></td></box>	ion>	<u> </u>		_	
•					

Operation Guide 7 for Project Management

After settings of Project Management, you could generate elevation, section, and 3D model.

Generate Elevations by Project Management

Objective: generate elevation by the model that built by all drawings of each floor. Methods: Building Elevation command.

Make sure that the project management documents have estable

- Make sure that the project management documents have established and all floor relationships are correct. Open project management file.
- (2) Click Building Elevation command and pay attention to command prompts;
- (3) Enter F according to command prompts to generate building elevation in front view;
- (4) Box select axis line according to command prompts and pay attention to the positions of p1 and p2;
- (5) In this sample, we selected four axes from number 1 to number 4, and press "Enter" to next step.



Operation Guide 1 for Elevation

(6) Click Generate Elevation button without modifying other parameters in dialog box

Building Elevation				
Basic Settings	Dimension			
 Multifloor hiddenline Removal(Quality Optimize) 	✓ Left Side			
O Singlefloor hiddenline Removal(Speed Optimize)	✓ Right Side			
Ground and Floor Level Difference(m): 0.45	✓ Draw Floor Lines ✓ Floor No. Mark			
Plot Scale 1: 100 🗸	Mark Between Two Floors			
	✓ Bracket			
Generate Elevation	Styles 1F 🗸			

Operation Guide 2 for Elevation

(7) The generated elevation will be saved as a new file, click Save button to continue.

6		Save As		×
⊕ ∋ - ↑ 🛽	« MyProject → Project-1	~ Ċ	Search Project-1	Q
Organize 🔻 Ne	w folder			:= • 🔞
Name	*	Date modified	Туре	Size
皆 plan.dwg		2016/1/19 9:34	DWG File	1,979 KB
File <u>n</u> ame:	1-3AxisElevation.dwg			~
Save as <u>t</u> ype:	dwg file(*.dwg)			~
Alide Folders			<u>S</u> ave	Cancel

Operation Guide 3 for Elevation

(8) The generated elevation will be opened and displays as below (2D drawing):





Generate Section by Project Management

Objective: generate section by model that built by all drawings of each floor.

Methods: Building Section command

- (1) Make sure that the project management documents have established and all floor relationships are correct. Open project management file;
- (2) Click Building Section command and pay attention to command prompts;
- (3) Select existed section line in drawing;
- (4) Box select axis line according to command prompts and pay attention to the positions of p1 and p2;



(5) Press Enter key after selecting axis and then click Generate Section button in the pop-up dialog box.

Building Section				
Basic Settings Multifloor hiddenline Removal(Quality Optimize) Singlefloor hiddenline Removal(Speed Optimize)	Dimension ✔ Left Side ✔ Right Side			
Ground and Floor Level Difference(m): 0.45	 ✓ Draw Floor Lines ✓ Floor No. Mark 			
Plot Scale 1: 100 🗸 🗸	Mark Between Two Floors			
Generate Section	Styles 1F 🗸			

Operation Guide 2 for Section

(6) The generated section will be saved as a new file, click Save button to continue.

e	Save As			×
🔄 🄄 🔻 🚹 « MyProject > Project	-1 v C	Search Project-1	م ا	>
Organize 🔻 New folder			!≡ ▾ ((2
Name	Date modified	Туре	Size	
🚰 1-3AxisElevation.dwg	2016/1/19 10:32	DWG File	15 KB)
🚰 plan.dwg	2016/1/19 9:34	DWG File	1,979 KB	1
File name: 1-1Section Drawing.dwg. Save as type: dwg file(*.dwg)	dwg			*
lide Folders		Save	Cancel	

Operation Guide 3 for Section

(7) The generated section will be opened and displays as below (2D drawing):



Operation Guide 4 for Section

Generate 3D model by Project Management

Objective: generate 3D model according to relationships of each floor

Methods: Floor Composite command

- Make sure that the project management documents have established and all floor relationships are correct. Open the project management file;
- (2) Click Floor Composite command;
- (3) Check Drag to Current Drawing option and click Ok;
- (4) Specify one point in drawing to place the 3D building model according to command prompts. The current viewport is a planning mode, rather than view of all aspects.

Tool Box 🛛 🗘 🗙	Project Manager	џ х 🗾 рlau	Floor Assemble
Grid Column/Beam/Slab Wall Door and Window Room and Roof Stair and Others 3D Modeling HFloor Composite Composite the 3D mode parturng Stree Slab	Project-1 Sheet Set Floor Table Floor Floor Flo	standard floors	Project File E:\MyProject\Project-1\Project-1.ipj Select Location of Generating O Drag to current drawing Generate a new drawing Method of Model Generating Explode into faces Insert as Blocks
-			OK Cancel



Operation Guide for 3D model

(5) Right click in the drawing area and pop-up right click menu and then select SE Isometric view in the menu. Now the model displays its 3D isometric view in the drawing.

	بر	-	
			Repeat the Command
			Inquiry
		•	Obeject Select
		Aq	Find and Replace
9	Dynamic Observation		Visual Settings
	Plane		Layer Tools
	Upward View	鞹	Draw Grid
	Left Elevation	=	Draw Wall
	Right Elevation	₽	Standard Column
	Front Elevation	,Da	Door/Window
	Back Elevation		U-Shaped Stair
	Axonometric drawing from southwest	F	Balcony
	Axonometric drawing from southeast		Rectangle
٩	Axonometric drawing from northeast	Т	single line text
٢	Axonometric drawing from from northwest	<u>T</u> ≣	Multi-line text
		Ħ	Linear Dimension
		19	DWG Library Managemen

Visual Settings

The generated DWG 3D model could be imported to some 3D software, such as SketchUp, and it could be edited and processed by them.

Summary

Through above cases, we have a certain understanding of professional drawing and modifying function provided by GCA; and we are familiar with Dimension, Symbols, and other operations; as well we know clearly the important role of Project Management played.

GCA provides many practical tools; you could access <u>www.gstarcad.net</u> for more related information.